



WI-127 Inbound/Outbound User's Manual

UNITED STATES

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

CANADA

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

Le present appareil numerique n'emet pas de bruits radioelectriques depassant les limites applicables aux appareils numeriques de la Class A prescrites dans le Reglement sur le brouillage radioelectrique que edicte par le ministere des Communications du Canada.

EUROPEAN COUNTRIES

WARNING

This is a Class A product. In a domestic environment this product may cause radio interference in which the user may be required to take adequate measures.



CAUTION

Risk of electrical shock. Do not remove cover. No user serviceable parts inside. Refer servicing to qualified service personnel.

Weigh-Tronix reserves the right to change specifications at any time.

Table of Contents

Table of Contents	3
Specifications	4
Introduction	5
Operations Mode	5
Front Panel	6
Keys	6
Standard Scale Keys	6
Function Keys	7
Keypad Keys	7
Directional Keys	7
Annunciators	7
Gross Weighing	8
Method 1: Inbound/Outbound Weighing	8
Capturing an Inbound or Outbound Weight	8
Inbound/Outbound Shortcut	9
Printing a Report	9
Editing and Deleting Channels	9
Method 2: Multiple Tare Registers	10
Defining Tare Registers	10
Creating New Registers or Accessing Existing Registers	10
Entering and/or Editing Tare Register Values	10
Clearing/Deactivating Tare Register Values	11
Editing and Deleting Tare Registers	11
Net Weighing	11
Printing a Report	11
Using Cutoff Registers	12
Viewing Cutoffs	12
Entering Cutoff Values	12
Clearing/Deactivating Cutoff Values	12
Checkweighing	13
Setting Target and Over/Under Values	13
Checkweighing Operation	14
Customizing the Indicator	14
Viewing and Setting Time	14
Viewing and Setting Date	15
Viewing and Editing the ID Number	15
Operations Menu	16
Description of Operations Menu	17
Serial Communication	18
Inbound/Outbound Printouts	18
Tare Register Printouts	19
Error Messages	20
Indicator Diagnostics	21
Test Mode	21

Pages are numbered consecutively beginning with the cover page.

Specifications

Power requirements:

115 Volts AC, +10% to -15% @ 0.3Amp maximum
230 Volts AC, +10% to -15% @ 0.15 AMP maximum
50/60 Hz

Excitation: 10 Volts DC

Supports up to twelve 350-ohm weight sensors

Operational keys:

Five yellow standard keys: Zero, Tare, Print, Units, Select

Three function keys: **INBOUND/OUTBOUND, TARE REGISTER, CUTOFF**

Numeric keys: 0-9

Operational annunciators:

Gross, Tare, Net, Print, Zero, Motion
Under, Accept, Over, Cutoff, ID,
Three units of measure

Display: Eight digit, seven segment, 0.8-inch high LED

Display rate: Selectable (1, 2, 5, 10)

Analog to digital conversion rate: 60 times per second

Unit of measure:

Three, independently programmable:
Pounds, kilograms, grams, ounces, ton, tonne, custom, Off

Capacity selections:

999,999 with decimal located from zero to five places

Incremental selections:

Multiples and sub-multiples of 1, 2, 5

Programmable selections:

Zero range, motion detection,
automatic zero tracking, five-point linearization.

Time and date/RAM:

Battery backed up real time clock and RAM are standard

Internal resolution: 6,291,456 counts per mV/V per sec.

Harmonizer™ digital filtering:

Fully programmable to ignore noise and vibration

Standard inputs:

Seven logic level inputs for functions such as tare, print, zero, units, select, gross and net.

Standard outputs:

Three outputs, open collector design
Relay power supply, 24 VDC at 150mA
Bi-directional serial port (RS-232 or RS-422/485 or 20mA current loop)

Self diagnostics:

Display, keys, inputs, outputs, serial port, A to D converter, loadcell output display, voltages

Circuitry protection: RFI, EMI, and ESD protection

Options:

Two additional serial ports
BCD parallel
10 cutoffs
Analog output
0-5, 0-10 volts
1-5, 4-20, 10-50 mA

Operating temperature:

-40 to 140° F (-40 to 60° C)
100% relative humidity including washdown

Enclosure: NEMA 4X stainless steel enclosure

Dimensions:

12" W x 8" H x 4" D (without mounting bracket)
12.3" W x 11.0" H x 5.3" D (with mounting bracket)

Weight: 12.5 lb, 5.7 kg

Introduction

The WI-127 Inbound/Outbound is a microprocessor-driven weight indicator designed to interface with an electronic scale. Its purpose is to calculate net weight value and to transmit serially that value, along with other weighing information, to a printer, computer, or programmable controller.

A hallmark of the WI-127 Inbound/Outbound indicator is its versatility in adapting to a broad range of weighing applications requiring calculation of net value.

Two methods of net weighing are available:

Method 1: Inbound/Outbound Weighing allows you to live-weigh an empty or full container (or vehicle, etc.), with or without transmission of data. Later you may live-weigh the same container for calculation of a net value and transmission of data. The indicator will select the larger weight as the gross weight and always transmit a positive net weight. The first weighing of the container stores its value in memory so that similar weighing operations can continue in up to 300 other channels between the time of the first weighing operation and the second. The indicator will keep track of the number of transactions and accumulate the totals for each inbound/outbound channel.

Method 2: Using Multiple Tare Registers allows you to store tares in two different ways. You may:

- Live-weigh an empty container and store its tare value in one of 300 tare registers. Then do multiple live weighings with the same refilled container or with containers of equal tare weight value. The WI-127 Inbound/Outbound Indicator will use the tare value you stored in memory for calculation of net value and transmission of data.
- Enter using the keypad a predetermined weight value in one of 300 tare registers. Then do multiple live weighings with filled containers equal in weight to the memory-stored value for calculation of net value and transmission of data.

The indicator will also keep track of the number of transactions and accumulate the totals for each tare register.

Operations Mode

Operations mode contains all normal weighing operations. In this mode you can view or set the following parameters:

- inbound/outbound channels
- multiple tare registers
- cutoff registers
- target, over and under values
- time
- date
- identification number

Front Panel

The WI-127's front panel consists of 24 keys and fourteen annunciators.




Figure 1
WI-127 Front Panel

Keys

Standard Scale Keys

The WI-127's keys are divided into four primary groups:

Standard Scale Keys	These yellow keys are common to a majority of weighing applications and include SELECT, TARE, PRINT, ZERO, and UNITS.
SELECT	Used to switch between the gross, tare, and net display modes. SELECT can also be used to accept a current selection and return to weigh mode from within any menu.
TARE	Enters a pushbutton tare in the display mode. Can be configured to accept values through the numeric keypad.
PRINT	Used to initiate manual data transmission.
ZERO	Zeros the scale in the display mode. Also clears values in numeric entry.
UNITS	Switches the units of measure in the display mode. Up to three units of measure are selectable.

Function Keys

Operation of these keys changes with the software installed in the WI-127. (standard, in-motion, GTN)

These oval keys, along the right side of the display face, are configurable and are labeled **INBOUND/OUTBOUND**, **TARE REGISTER**, and **CUTOFF**. The default configurations for these keys are:

INBOUND/OUTBOUND	Accesses inbound/outbound GTN weighing function (see <i>Method 1</i>)
TARE REGISTER	Accesses multiple tare registers (see <i>Method 2</i>)
CUTOFF	Accesses cutoff registers (see <i>Cutoff Registers</i>)

Keypad Keys

These are the twelve square keys which support numeric entry. The keyboard keys are labelled 0-9, plus/minus (+/-), and decimal point (.) and are located near the center of the display face.

Directional Keys

The directional keys are used to navigate through the WI-127's menus. These keys are labeled ESCAPE (up), ENTER (down), ← (left), and MENU (right) and are positioned in a compass-like cluster on the display face. These directional keys are denoted by the small transparent arrows located next to them. ESCAPE, ENTER, and ← also support numeric entry.

ESCAPE	Exits a menu parameter without saving any changes.
ENTER	Used to end digit entry, accept a change made, or select an item from a function list.
←	Backspaces (deletes the last digit or punctuation mark entered) while in numeric entry and moves left within a menu.
MENU	Accesses menus and moves right within a menu.

Annunciators

The WI-127 has fourteen annunciators.

Gross	Illuminates when indicator is in gross weighing mode.
Tare	Illuminates when viewing tare values in the various tare registers.
Net	Illuminates when indicator is in net weighing mode.
lb, kg, other	Illuminates the active unit of measure in weighing mode.
Print	Illuminates when the indicator is transmitting data.
Zero	Illuminates when the scale is within $\pm 0.25\%$ of increment center of zero.
Motion	Illuminates when the scale detects motion (within configured motion window).
Under, Accept, Over	Illuminates relative to respective values stored.
Cutoff	Illuminates when a cutoff entry is made.
ID	Illuminates in special display mode during which inbound and outbound (net) weights are displayed.

Gross Weighing

- To perform gross weighing operations, follow these steps:
1. Power up the indicator.

Indicator powers up in gross weighing mode.

2. Verify the scale is empty and zero the scale by pressing the **ZERO** key.

Zero weight is displayed and the zero annunciator illuminates.

3. Select unit of measure by pressing the **UNITS** button.

The units annunciator will illuminate next to the chosen unit of measure.

4. Place weight on the scale.

Gross weight is displayed.

Method 1: Inbound/Outbound Weighing

Capturing an inbound or outbound weight

The **INBOUND/OUTBOUND** key will work only if the indicator is in gross weighing mode.

Channel numbers may be from 1 to 6 numerals in length.

If a new channel was created or if the existing channel had no value for the inbound weight, the captured weight is stored as the inbound weight.

If the channel already had an inbound weight, the captured weight is stored as the outbound weight and is added to the accumulator total. After the outbound weight is printed, the inbound weight is cleared from the channel.

- The inbound/outbound weighing function stores inbound weight and time and date information in up to 300 channels. Then, when the outbound weighment is stored, the indicator performs an accumulation and prints the net weight.
1. From gross weight display mode, press **INBOUND/OUTBOUND**.

_____ is displayed, prompting for a channel number.

2a. Enter a channel number using the keypad (this will either create a new channel or call up a previously entered one), or

2b. Use the **MENU** (forward) and **←** (backward) keys to select a previously entered channel . . .

The channel number is displayed.

3. With weight on the scale, press **ENTER** . . .

The weight is captured and the indicator prints the transaction. At the end of an inbound/outbound operation, the inbound and net weights are displayed respectively for four seconds. The ID annunciator illuminates during this special mode.

Inbound/outbound shortcut


To eliminate a keystroke, use the following shortcut for capturing a weight:

1. With weight on the scale, enter the channel number using the keypad . . . Channel number is displayed.
2. Press **INBOUND/OUTBOUND**. The weight is captured and the indicator transmits the transaction to a peripheral printer.

Printing a report

This utility is accessed from the Operations Menu shown in Figure 2. You may follow the steps below or refer to Figure 2 for a visual representation.

1. From weight display mode, press **MENU** . . . *G.t.n.* is displayed.
2. Press **ENTER** . . . *rEPort* is displayed.
3. Press **ENTER** . . . A report is printed. The default printout is a report of the GTN database information for each channel.
4. To return to weight display mode, press **SELECT**.



The image shows a sample printout of an inbound/outbound report. It is enclosed in a rectangular frame with a dashed border. The top line of the report displays the time and date: "10:31 AM 04-07-97". Below this, there are two columns: "Truck#" and "Net Total". The first section of the report lists five trucks with their respective net totals: Truck 1 (1000 lb), Truck 2 (1500 lb), Truck 3 (1000 lb), Truck 4 (1500 lb), and Truck 5 (0 lb). Below this section, there is another section titled "Truck#" and "Inbound". This section lists Truck 5 with an inbound weight of 2000 lb.

Truck#	Net Total
1	1000 lb
2	1500 lb
3	1000 lb
4	1500 lb
5	0 lb

Truck#	Inbound
5	2000 lb

An inbound/outbound report prints:

- the time and date
- all truck numbers in the database and their corresponding net totals
- all truck numbers that only have an inbound weight and their net totals.

Sample Inbound/Outbound Report

Editing and Deleting Channels

You may delete any or all of the channels in your WI-127. To do so, you must access the Operations Menu (Figure 2). The complete menu and descriptions are in the "Customizing the Indicator" section. Please refer to that section.

If your indicator is configured to allow editing of the inbound/outbound channels, you may also: the inbound hour, the inbound date, the accumulator value, and the transaction counter.

Method 2: Multiple Tare Registers

Defining Tare Registers

Creating New Registers or Accessing Existing Registers

The multiple tare function provides up to 300 tare registers. Tare weights may be entered as a live weight (pushbutton tare) or as a keypad entered weight.

Use these instructions for creating new tare registers or for accessing previously entered registers. Up to 300 registers may be used.

1. From weight display mode, press **TARE REGISTER . . .**

The current tare register number is displayed. (If no tare registers are present, **—** is displayed, prompting you to enter a tare register number.)
- 2a. If creating new registers, enter in the register number using the keypad, or
- 2b. If registers already exist, enter in the register number using the keypad, or use the **MENU** (forward) and **←** (backward) keys to select a tare register . . .

The tare register number is displayed.
3. Press **ENTER . . .**

The tare value in that register is displayed.

You are now ready to enter tare values into these registers. Follow the instructions in the following section *Entering and/or Editing Tare Register Values*.

Entering and/or Editing Tare Register Values

Once you have accessed a tare register, you may enter new tare values or edit existing values. Following is the standard procedure.

1. With the tare value displayed, you can enter/edit a tare value in a register in two ways:
 - a. **Key in a tare value:**
Key in your desired tare value using the keypad, then press **ENTER . . .**

The tare value is accepted and the indicator returns to net display mode.
 - or
 - b. **Use the pushbutton tare:**
With the tare weight on the scale, press **TARE . . .**

The new tare value (the weight on the scale) is displayed and accepted.

Clearing/Deactivating Tare Register Values

To clear a tare register value, use the keypad to set the value to zero.

Editing and Deleting Tare Registers

Multiple tare registers in the WI-127 may be edited: you may change the tare value, the net accumulator total, and the transaction counter. You may also clear values from individual or multiple registers and you may delete any or all of the tare registers.

To edit and delete tare registers, you must access the Operations Menu (Figure 2). The complete menu and descriptions are displayed in the section *Customizing the Indicator*. Please refer to that section for editing and deleting.

Net Weighing

*You may view the current or active tare value at any time during a weighing process. From gross or net weighing mode, press **SELECT** until the tare annunciator illuminates. If a tare value is in use, it will be displayed.*

To perform net weighing with a tare register, the register must already exist and have a tare value stored in it. If you have already set up your tare registers and are ready to perform net weighing operations, proceed to the next section. If you still need to create your tare registers, refer to the section *Defining Tare Registers* on the previous page.

1. From the weight display mode, enter the desired tare register number using the keypad . . . Tare register number is displayed.
2. Press **TARE REGISTER** . . . Tare value is displayed in net mode.
3. Place weight on the scale . . . Net weight is displayed.
4. Press **PRINT** . . . A printout including time, date, tare register number, and gross, tare, & net weights is performed.

Printing a Report

This utility is accessed from the Operations Menu shown in Figure 2. You may follow the steps below or refer to Figure 2 for a visual representation.

1. From weight display mode, press **MENU** . . . **G.t.n.** is displayed.
2. Press **MENU** again . . . **tArES** is displayed.
3. Press **ENTER** . . . **rEPorT** is displayed.
4. Press **ENTER** again . . . A report is printed. The default printout is a report of the tare database information for all active tare registers. (See *Method 2* for an example of the default printout.)
5. To return to weight display mode, press **SELECT**.

Cutoff Registers

The standard WI-127 includes three cutoffs. Adding the optional cutoff card raises this number to ten.

When activated (weight on the scale is less than the weight in the cutoff registers), these cutoffs are all on at the same time. Each cutoff will deactivate as soon as the weight on the scale matches the value in each cutoff register.

Cutoffs may be positive or negative values.

Cutoff registers may be viewed by two methods:

Method A:

1. Press the **CUTOFF** key. . . **1 xx** is displayed. The number 1 stands for cutoff register #1 and xx is the current value in register 1.
2. Continue pressing **CUTOFF** or **MENU** to scroll forward or **←** to scroll backward through the remaining cutoff registers.

Method B:

If you know which cutoff register you wish to view, press the number of that register, then press **CUTOFF**. That particular cutoff register is displayed. You may scroll through the remaining registers by pressing the **CUTOFF** key consecutively.

To enter a cutoff value,

1. Press **CUTOFF** until the cutoff register you wish to set is displayed. **3 0** (for example).

2. Enter the cutoff value in one of two ways:

2A. Key in the correct cutoff value using the keypad . . . **3 xx** is displayed.

or

- 2B. With active weight on the scale, press **TARE** . . .

The active weight is set as the cutoff value.

3. Press **MENU** or **CUTOFF** to accept the value and move to the next cutoff register.

4. To return to weight display mode, press **SELECT**.

To deactivate or clear a cutoff value, set the value to zero.

Viewing cutoffs

Press **ENTER** at any time to exit the cutoff register menu.

Entering cutoff values

Press **ENTER** at any time to exit the cutoff register menu.

Clearing/deactivating cutoff values

Checkweighing

Setting Target and Over/Under Values

The ACCEPT annunciator does not illuminate when target = 0.

The WI-127 is configured to perform checkweighing functions. The checkweighing parameters are accessed through the Operations Menu shown in Figure 2.

The target value must be considered when determining values to enter for over and under. Depending on the target values, the over/under values can be entered as either actual weight values or as tolerance values.

If the target value is zero, you may enter over and under values as actual weight. For example, if the **target** = 0, **over** might = 100 lbs, and **under** might = 50 lbs. This means that any weight between 50 lbs and 100 lbs is acceptable.

If the target value is a value other than zero, the over and under values must be set as tolerances. For example, if **target** = 100, **over** might = 10, and **under** might = -10. This means that any weight between 90 and 110 lbs is acceptable.

1. Press **MENU** until. . . **boundS** is displayed.
2. Press **ENTER** . . . **OVER** is displayed.
3. Press **ENTER** . . . The over tolerance is displayed and the **OVER** annunciator illuminates.
4. Using the keypad, enter the new over tolerance value. . . New value is displayed.
5. Press **ENTER** . . . **OVER** is displayed.
6. Press **MENU** . . . **UndEr** is displayed.
7. Press **ENTER** . . . The under tolerance is displayed and the **UNDER** annunciator illuminates.
8. Enter the new under tolerance value. . . New value is displayed.
9. Press **ENTER** . . . **UndEr** is displayed.
10. Press **MENU** . . . **tArgEt** is displayed.
11. Press **ENTER** . . . The target value is displayed and the **ACCEPT** annunciator illuminates.
12. Enter the new target value. . . New value is displayed.
13. Press **ENTER** . . . **tArgEt** is redisplayed.
14. After entering all new values, press **SELECT** . . . Indicator returns to display mode.

Checkweighing
Operation

1. With the indicator in display mode, verify the scale is empty and zero the scale by pressing the **ZERO** key. . .

Zero weight is displayed and the zero annunciator illuminates.
2. Select the unit of measure by pressing the **UNITS** button. . .

The units annunciator will illuminate next to the chosen unit of measure.
3. Place weight on the scale. . .

Weight will be displayed and the *UNDER*, *ACCEPT* or *OVER* annunciator will illuminate.

Customizing the Indicator

Viewing and Setting
Time

The ID number, time, and date are accessed through the Operations Menu shown in Figure 2. You may follow the instructions in this section or refer to Figure 2 for a visual representation.

1. From display mode, press **MENU** until. . .

Hour is displayed.
2. Press **ENTER**. . .

The current time is displayed.
In the 12-hour clock configuration time is displayed as hours, minutes, and **A** for A.M. and **P** for P.M. (e.g. **09 40 A**).
In the 24-hour clock configuration time is displayed as hours, minutes, and seconds (e.g. **09 40 30**).
3. Press **UNITS** to toggle between the 12 hour and 24 hour clocks.
4. **To set the 12 hour clock:**
a. Key in the time as **hh mm**.
b. Press the **+/-** key to toggle between A.M. & P.M.
c. After the correct time is entered, press **ENTER** to accept the new time.

To set the 24 hour clock:
a. Key in time as **hh mm ss**.
b. After the correct time is entered, press **ENTER** to accept the new time.
5. Press **ENTER** to view the new time. . .

The new time is displayed.
6. Press **ESCAPE** to return to display mode. . .

Indicator returns to display mode.

If you enter an incorrect digit, press ← to clear the display one digit at a time.

Viewing and Setting the Date

If you enter an incorrect digit, press ← to clear the display one digit at a time.

1. From display mode, press **MENU** until. . . **dAY** is displayed.
2. Press **ENTER**. . . The date is displayed as month-day-year.
3. To change the date, key in the new date using the numeric keypad (the entire date must be entered), then press **ENTER**. . . The new date is accepted and **dAY** is redisplayed.
4. Press **ENTER** again to view the new date
or
Press **ESCAPE** to return to display mode. . . Indicator returns to display mode.

Viewing and Editing the ID Number

Viewing the ID number

The ID number may be up to 8 digits in length. It may include any combination of the numbers 0 through 9, dashes, and one decimal point.

1. From display mode, press **MENU** until. . . **id.** is displayed.
2. Press **ENTER**. . . The current ID number is displayed.
3. After viewing, press **ESCAPE**. . . Indicator returns to display mode.

Editing the ID number

1. From display mode, press **MENU** until. . . **id.** is displayed.
2. Press **ENTER**. . . The current ID number is displayed.
3. Enter your new ID number using the keypad. If you make a mistake entering the new ID number, use the ← key to backspace and delete the incorrect digits. . . New ID number is displayed.
4. With your new ID number displayed, press **ENTER**. . . The new ID number is saved and the indicator returns to display mode.

Operations Menu

Your WI-127 is configured to display and edit inbound/outbound functions, multiple tare registers, time, date, identification number, and checkweighing functions in the Operations Menu. These parameters can be viewed and changed if allowed. **This manual assumes the unit is configured to allow full access to these functions.**

To enter the Operations Menu press **MENU**. Use the directional keys to maneuver through this menu:

ESCAPE = up
ENTER = down
← = left
MENU = right




Figure 2
Operations Menu

Description of Operations Menu

Following are descriptions of the various options in the Operations Menu. The indentations represent levels within the menu.

G.T.N.	Accesses inbound/outbound functions (Method 1).
Report	Prints the group assigned to this function.
Edit	Allows viewing/editing of channel information. When the edit parameter is sealed, values may be viewed only, not edited (refer to the Service Manual).
XXX	The current channel is displayed as the default. Scroll through the existing channels by using the MENU (forward) and ← (backward) keys.
Inbound	Displays inbound value. None will be displayed if an inbound weight does not exist. Press "0" and ENTER to clear the inbound weight.
Hour In	Displays time of inbound weight. This parameter is only offered if an inbound weight already exists.
Day In	Displays date of inbound weight. This parameter is only offered if an inbound weight already exists.
Total	The net accumulator value for the selected channel.
Counter	The transaction counter for the selected channel.
Delete	Allows user to clear the channel database. If the database is already clear, dOnE will be displayed and the remaining parameters will not appear.
Done	Offered only if the database is empty.
No	Will not delete the channels. Not offered if database is empty.
One	Allows user to select a specific channel to delete. Not offered if the database is empty.
All	Allows user to delete all channels at one time. Not offered if database is empty.
TARES	Accesses multiple tare registers (Method 2)
Report	Prints the group assigned to this function.
Edit	Allows viewing/editing of channel information.
XXX	The current tareregister is displayed as the default. Scroll through the existing registers by using the MENU (forward) and ← (backward) keys.
Tare	Displays the current tare value.
Type	Displays the type of tare. Pb indicates a pushbutton tare entered by using the TARE key. EntErEd indicates a tare that was entered through the keypad.
Total	The net accumulator value for the selected register.
Counter	The transaction counter for the selected register.
Clear	Allows user to clear the accumulators and transaction counters for the tare registers. Not offered if the database is empty.
No	Will not clear the accumulators and counters.
All	Clears the accumulators and counters for all tare registers but leaves the tare values intact.

Delete	Allows user to delete tare registers. If there are no tare registers to delete, dOnE will be displayed and the remaining parameters will not appear.
Done	Offered only if the register database is empty.
No	Will not delete the registers. Not offered if database is empty.
One	Allows user to select a specific tare register to delete. Not offered if the database is empty.
All	Allows user to delete all tare registers at one time. Not offered if database is empty.
HOURL	Allows the user to set the time.
DAY	Allows the user to set the date.
ID	Allows the user to select and change the indicator's identification number.
BOUNDS	Provides access to the checkweighing parameters.
Over	Allows user to set the over value.
Under	Allow the user to set the under value.
Target	Allows the user to set the target value.

Serial Communication

The WI-127 has a bi-directional serial port with RS-232, RS-485/422 or 20 mA current loop communication capability. Your unit may be customized to print according to your needs. Refer to a Service Manual for instructions on customizing the printouts.

Following are examples of the five default printouts of the WI-127.

Method 1: Inbound/Outbound Printouts

Inbound Ticket

```

Date 04-07-97
Inbound Time 10:30 AM
Truck#      4
Transaction  1
Weight 1500 lb

```

An inbound ticket prints the date, inbound time, truck number, transaction number, and inbound weight. This ticket is automatically printed after each transaction/

Outbound Ticket

```

Date 04-07-97
Inbound Time 10:30 AM
Outbound Time 10:30 AM
Truck#      4
Transaction  1

Gross 3000 lb
Tare  1500 lb
Net   1500 lb

```

An outbound ticket prints the date, inbound time, outbound time, truck number, transaction number, and the gross, tare and net weights. This ticket is automatically printed after each transaction.

Inbound/Outbound Report

10:31 AM 04-07-97	
Truck#	Net Total
-----	-----
1	1000 lb
2	1500 lb
3	1000 lb
4	1500 lb
5	0 lb
Truck#	Inbound
-----	-----
5	2000 lb

An inbound/outbound report prints the time and date, all truck numbers in the database and their corresponding net totals, and all truck numbers that only have an inbound weight and their net totals. The Operations Menu must be accessed to print this report.

Method 2: Tare Register Reports

Tare Transaction

10:46 AM 04-07-97	
Tare#	4
Gross	3000 lb
Tare	2000 lb KP
Net	1000 lb

When the **PRINT** key is pressed while using a tare register, a printout is performed which includes time, date, the tare register number, and gross, tare, and net weights. The tare weight includes the type of tare: KP if the tare was entered via the keypad or PB if the tare value was entered using the **TARE** key.














Tare Report

10:46 AM 04-07-97	
Tare#	Net Total
-----	-----
1	0 lb
2	1500 lb
3	0 lb
4	1000 lb
5	0 lb
Tare#	Tare wt.
-----	-----
1	500 lb PB
2	1000 lb KP
3	1500 lb PB
4	2000 lb KP
5	1000 lb PB

A tare register report includes, time, date, all existing tare registers with their net totals, and all existing tare register with their tare values and type of tare. The Operations Menu must be accessed to print this report.

Error Messages

The following are displays you may see if problems occur or if invalid operations are attempted with your WI-127:

Display	Description
	Overrange weight.
	Underrange weight.
	Recovering from lock-up or out of range condition.
	A-D converter is not functioning.
	A-D converter subjected to an input signal beyond ± 5.00000 mV/V
	The unit cannot perform a function. Displayed only while key is held down.
	Corrupted data in the reset menus. See the <i>Service Manual</i> . (* = RESET, SETUP, or CAL)
	Displayed while a key is pressed when attempting to modify a sealed selection without edit privileges.
	Displayed while waiting for a stable, valid weight to use as a zero reference on power-up.
	Displayed when input voltage to excitation regulator drops below 10.5 VDC. Will clear when input voltage rises above 11.5 VDC.
	Displayed when the ready/busy handshake has exceeded its time out limit. Default is 2 seconds. This can also apply to optional 2nd and 3rd serial ports.
	Displayed when the net accumulator exceeds its maximum value. Message will appear when trying to view the accumulator total.
	Displayed if the tare register value does not exist and the memory is full. Displayed only while key is held down.

Indicator Diagnostics

Test Mode

The test mode is used to test various functions of the WI-127. The test menu is shown in Figure 3.

To enter the test menu:

1. Press and hold **ESCAPE** for two seconds. . . **About** is displayed.
2. Press **MENU** two times. . . **tEst** is displayed.
3. Press **ENTER**. . . **diSPLAY** is displayed.

Maneuver through the parameters using the directional keys:

ESCAPE = up
ENTER = down
← = left
MENU = right

You may exit to display mode at any time by pressing **SELECT**.




Figure 3
Test Menu

Below are the explanations for the items you see in the test menu.

- Display —** Performs a test of the display segments and LEDs. With **diSPLAy** displayed, press **ENTER** once to initiate an automatic test. Press **ENTER** again to stop the automatic test, or press **↶** and **MENU** consecutively to step through the display test manually. Press **ESCAPE** to exit the display test.
- Buttons —** Performs a test of the keypad. With **buttonS** displayed, press **ENTER** and the word **nOnE** will appear on the screen. Press any key except **MENU** to check for proper key functioning. The title of each key will appear on the display as it is pressed. After testing the buttons, press **MENU**.
- A to D —** Performs A-to-D test to check the raw offset and gain of the electronics. With **A to d** displayed, press **ENTER** to view the A-to-D value. The span is 20,000 counts per millivolt per volt. Press **ESCAPE** to return to **A to d**.

Loadcell —	Displays the factory normalized loadcell input. With LOADCELL displayed, press ENTER to view the counts. Press UNITS to toggle between the counts display mode and mV/V display mode. Span is 200,000 counts per millivolt per volt. Press ESCAPE to return to LOADCELL .
Serial —	Allows testing of the internal serial ports. With SERIAL displayed, press ENTER to select the port to test. Port 1 is always the internal serial port. (Port 2 and 3 are only offered if extra serial ports are installed.) Press ENTER again to view ready/busy. Then press MENU to view loop/no loop. Press ESCAPE to return to SERIAL .
Outputs —	Allows testing of the outputs. With OutPutS displayed, press ENTER twice to cycle through the available outputs in sequential order. Press ESCAPE—SEqUEnCE is displayed. Press MENU to view the available outputs. Press ENTER to view the status of the outputs. The outputs are numbered left to right, starting with one. A "1" indicates the output is activated; a "0" indicates the output is deactivated. To change the status of the output, move the decimal point to the right of the output you wish to change. Toggle the status by pressing ENTER . If the optional I/O board is installed, an additional eight outputs are available under Out. 9-16 . Press ESCAPE to return to OutPutS .
Inputs —	Allows testing of the inputs. With InPutS displayed, press ENTER—StAndArd is displayed. Press ENTER again to view the status of each input. The inputs are ordered 1-8 from left to right. A "1" indicates the input is activated; a "0" indicates the input is deactivated. If the optional I/O board is installed, an additional eight inputs are available under OPtion . Press ESCAPE twice to return to InPutS .
Voltages —	Allows testing of the power supply voltages. With VoltAGES displayed, press ENTER to test the unregulated loadcell excitation power supply voltage (13 volts). Press MENU repeatedly to scroll through the remaining power voltages: the -5 volt excitation voltage (-5 volts), the unregulated 5 volt logic supply voltage (10 volts), and the relay supply voltage (24 volts). Press ESCAPE to return to VoltAGES .

Avery Weigh-Tronix



Avery Weigh-Tronix USA

1000 Armstrong Dr.
Fairmont MN 56031 USA
Tel: 507-238-4461
Fax: 507-238-4195
Email: usinfo@awtxglobal.com
www.wtxweb.com

Avery Weigh-Tronix UK

Foundry Lane,
Smethwick, West Midlands,
England B66 2LP
Tel: +44 (0) 8453 66 77 88
Fax: +44 (0)121 224 8183
Email: info@awtxglobal.com
www.averyweigh-tronix.com